

Instructions for Installers

Ultrafonic Wall-Mounted Acoustic Modules

Handle with Care

Unpack and install with light weight cotton or poly/cotton gloves.

Hold modules by the outside frame, keep thumbs close to the edge on the front surface, within 25mm of the edge.

Do not apply pressure to the front on the module.

Installing

Install the modules closest to the floor first, a 25mm clearance above the module is required when mounting the module onto the rail.

Install the TOP mounting rail first.

Install the bottom rail 3mm lower than a perfect fit to make mounting easier. The bottom rail is not load bearing (see image below).

ultrafonic

